

BOUNCE HOUSES AND PLAY INFLATABLES

Anchoring



Tucson Fire Department
300 S. Fire Central Pl.
Tucson, AZ. 85701
(520) 791-4502



ANCHOR POINTS

- Anchor points are attachment points for anchors that are part of a bounce house/inflatable located at the base of the house.
- All points shall be anchored.
- 18" stake minimum. Shall be anchored all the way in the ground
- Longer stakes shall be anchored a minimum of 75% length of stake in the ground.
- All other anchor types (sandbags, blocks, etc.) shall be a minimum 75 lbs. at each anchor point. Anchors shall be attached to anchor points.
- All anchor types shall be used solely for anchoring (i.e., no use of fences, vehicles, etc. as anchors).

SIDE POINTS

- Side points are attachment points for anchors that are located near the middle or top of the inflatable. These typically are on larger inflatables, slides, and obstacle courses.
- All side points shall be anchored.
- 30" stake minimum. Shall be anchored all the way in the ground.
- Slides shall have 150 lbs. of anchoring minimum on each side point.

WIND

- Bounce houses shall not be utilized in 25 mph winds or greater.