



## NOTES:

1. BACKFLOW ASSEMBLY SHALL BE INSTALLED, MAINTAINED AND TESTED IN ACCORDANCE WITH STATE AND LOCAL CODES AND REGULATIONS.

WATER MAIN CONSTRUCTION

- 2. TEMPORARY CONNECTION TO EXISTING POTABLE MAIN MUST BE APPROVED BY A TUCSON WATER CONSTRUCTION INSPECTOR.
- 3. WATER TO BE USED FOR FILLING AND FLUSHING OF NEW WATER MAINS ONLY.
- 4. BACKFLOW ASSEMBLY SHALL BE TESTED (EACH TIME) UPON INSTALLATION AND TEST REPORT SUBMITTED TO TUCSON WATER BACKFLOW PREVENTION/RECLAIMED WATER SECTION.
- 5. BACKFLOW ASSEMBLY IS REQUIRED TO BE TURNED OFF AT BOTH SHUT OFF VALVES AND REMAIN OFF WHEN CHLORINATING NEW MAIN.
- 6. DO NOT LEAVE BACKFLOW ASSEMBLY CONNECTED TO HYDRANT WITHOUT WATER METER. INSTALLATION MUST COMPLY WITH STANDARD DETAIL AT ALL TIMES.

ISSUED:	<b>WATER</b>	STANDARD DETAIL BACKFLOW PREVENTION POTABLE	ANTUCSON WATER	DETAIL NO.
7/08		WATER MAIN TEMPORARY		OD 1000
REVISED:		CONNECTION FOR TESTING AND FLUSHING OF NEW WATER MAINS ONLY		SD-1809
02/17				SHEET 1 OF 1