

CERTIFICATION by CUSTODIAN of RECORDS

Tucson Police Department Crime Laboratory 270 S. Stone Avenue Tucson, AZ 85701-1917

SC 6/10/1)

	ا ، او ، ال
I hereby certify that these documents are a true and correct copy of the periodic maintenance* for the Intoxilyzer 8000 Serial Number	
<u>Sv-002265</u> maintained by the Tucson Police Department	
Crime Laboratory pursuant to the requirements of the Arizona Department	
of Public Safety for a quality assurance program.	
A quality assurance specialist (QAS) tested the instrument on the following	
dates. The acceptable accuracy limits, as defined in A.A.C. R13-10-104.A.2, for a 0.100AC solution are 0.090AC to 0.110AC.	
101 a 0.100AC solution are 0.090AC to 0.110AC.	
Date: 6-2-11 Cal 1 0.101 AC Cal 2 0.100 AC	
Between the dates of 5-5-11 and 6-2-11 the instrument was operating properly and accurately.	_
and moderation was operating property and accuratory.	
The instrument was taken out of service for repair on	
The instrument was returned to service on NIA.	
Λ	
Clare Cooling	
Clare L. Conley	
6-3-11	
ADPS QAS Permit # 33314	
SUBSCRIBED AND SWORN to before me this 300 day of	
SUBSCRIBED AND SWORN to before me this 300, day of , 20 1/.	
, 20 11.	
Safell Trinllo	
OFFICIA	LSEAL
Notary Public ISABEL C.	IRUJILLO
PIMA C	OUNTY
*Includes documents specified in A.A.C. R13-10-104.A.5	July 16, 2012

Pursuant to section 28-1327, Arizona Revised Statutes, this document is a certified duplicate of the information contained in computer storage devices of the Tucson Police Department.

EXHIBIT G-4

THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104(A)



ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES INTOXILYZER MODEL 8000

50/10/11

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPE	6-2-11	AGENCY	Tucson Police Department
DATE _	6-2-11	TIME	1110
	LYZER SERIAL # 80-702265		
	1. Display reads "PUSH BUTTON TO		
DIAGNO	STIC TESTS		
	 Clock time check. Date check. 		
OPERAT	IONAL TESTS		
<pre>(</pre>			
COMMEN	Is Vone.		
	Λ Λ Λ Λ		
SIGNAT	URE Clave Conlin		

DPS Form Exh G-4 (Rev. 05-01)

2 M

INTOXILYZER 8000

Location: TUCSON POLICE DEPT

Serial Number: 80-002265

06/02/2011

11:12:08

50

Standard Lot#: 20910100A1 Last Changed By: C. STRAUB	#50772
QAS: C. CONLEY TUCSON PD	#34517
Operator: C. CONLEY	#34517

Subject: TEST, SQAP

DOB: 11/11/1111

Sex: M

Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	11:12:54
Diagnostic Test	Pass	11:13:21
Air Blank	0.000	11:13:48
0.100 Cal Check	0.100	11:14:07
Air Blank	0.000	11:14:37
Subject Test	0.000	11:14:54
Air Blank	ABT*	11:15:00
Air Blank	0.000	11:15:28

^{*}Sequence Aborted

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: TUCSON POLICE DEPT

Serial Number: 80-002265

06/02/2011

Standard Lot#: 20910100A1 Last Changed By: C. STRAUB #50772

11:15:33

OAS: C. CONLEY #34517

TUCSON PD

Operator: C. CONLEY #34517

TUCSON PD

Subject: TEST, SQAP

DOB: 11/11/1111 Sex: M Weight: 111

15 Minute Deprivation Period? Yes

Test g/210L Time Air Blank 11:16:03 RFI* Air Blank IPS** 11:16:15

*RFI Detect

storage devices of the Tucson Police Department.

**Improper Sample

Not a Successfully Completed Test Sequence

Pursuant to section 28-1327, Arizona Revised Statutes, this document is a certified duplicate of the information contained in computer

50

4067 CM

INTOXILYZER 8000

Location: TUCSON POLICE DEPT Serial Number: 80-002265

06/02/2011

11:16:21

Standard Lot#: 20910100A1
Last Changed By: C. STRAUB #50772

QAS: C. CONLEY #34517
TUCSON PD

Operator: C. CONLEY #34517
TUCSON PD

Subject: TEST, SQAP DOB: 11/11/1111

Sex: M

Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	11:17:06
Diagnostic Test	Pass	11:17:33
Air Blank	0.000	11:18:01
0.100 Cal Check	0.100	11:18:20
Air Blank	0.000	11:18:49
Subject Test	0.064*	11:21:57
Air Blank	0.000	11:22:29
Air Blank	0.000	11:22:56
Subject Test	XXX**	11:23:17
Air Blank	0.000	11:23:51

^{*}Deficient Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

Pursuant to section 28-1327, Arizona Revised Statutes, this document is a certified duplicate of the information contained in computer storage devices of the Tucson Police Department.

5

^{**}Invalid Sample

SC

INTOXILYZER 8000

Location: TUCSON POLICE DEPT Serial Number: 80-002265

06/02/2011

11:24:08

Standard Lot#: 20910100A1

Last Changed By: C. STRAUB #50772

QAS: C. CONLEY #34517

TUCSON PD

g/210L Time Air Blank 0.000 11:24:35 0.100 11:24:54 Cal Check 11:25:24 Air Blank 0.000

EXHIBIT G-2

6567

THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104(A)

SC 6/10/17

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA Special.	ist Clare Conley AGI	NCY Tue	cson Police	Department
DATE 6-2	2-\ TIP	4E 7110		4
	r Serial # 80 - 00 2265 Loc			
*	Ensure that gas tank is attack standard alcohol concentration OR Pour a standard alcohol con into a clean dry simulator and that a tight seal has been mallow temperature to reach 34°	solution centration d assemblade. Tur	on solution the simulation on the s	AC. AC, ator. Ensure
(/) 2.	Intoxilyzer 8000 display r	eads "PT	USH BUTTON	TO START"
(V) 3 ₁ .	Go to the "Control Testin control test or "W" for selection is made press EN	g Menu" wet	. Select "	D" for dry
() 4.	Air blank completed.			
() 5.	Calibration check complete	d. Test	results 0	. <u>/07</u> AC.
() 6.	Air blank completed.			
	Remove printed record. Att checklist.	ach the	record to t	he completed
SIGNATURE	Clave Conly			

DPS Form Exh G-2 (Rev. 05-01)

INTOXILYZER 8000

Location: TUCSON POLICE DEPT

Serial Number: 80-002265

06/02/2011

11:10:44

Standard Lot#: 20910100A1

Last Changed By: C. STRAUB #50772

QAS: C. CONLEY #34517

TUCSON PD

Test	g/210L	Time
Air Blank	0.000	11:11:12
Cal Check	0.101	11:11:31
Air Blank	0.000	11:12:00

50