

EXHIBIT G-4

THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY
A.A.C. R13-10-104(A)

1 of 7
TS4

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

SC
3/1/13

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST Terry Gallegos 28847 AGENCY Tucson Police Department
DATE 2-7-2013 TIME 0856
INTOXILYZER SERIAL # 80-002759 LOCATION ODE

() 1. Display reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- () 1. Clock time check.
- () 2. Date check.

OPERATIONAL TESTS

- () 1. Alcohol-free subject test result 0. 000 AC.
- () 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
- () 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
- () 4. Standard Calibration Check standard 0. 100 AC
Result: 0. 096 AC

Instrument is operating properly and accurately. YES NO

COMMENTS

SIGNATURE Terry Gallegos

INTOXILYZER 8000
Location:
Serial Number : 80-002759
02/07/2013 08:57:48

2 of 7
TSG

Standard Lot#: 23511100A2
Last Changed By: T. GALLEGOS #28847

50

QAS: T. GALLEGOS #28847
TUCSON PD

Operator: T. GALLEGOS #28847
TUCSON PD

Subject: TEST, SQAP
DOB: 11/11/1987
Sex: F Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	08:58:42
Diagnostic Test	Pass	08:59:09
Air Blank	0.000	08:59:37
0.100 Cal Check	0.097	08:59:55
Air Blank	0.000	09:00:25
Subject Test	0.000	09:00:48
Air Blank	0.000	09:01:16
Five Minute Wait	ABT*	
Air Blank	0.000	09:01:54

*Sequence Aborted

Not a Successfully Completed Test Sequence

30f7
TJh

INTOXILYZER 8000
Location:
Serial Number : 80-002759
02/07/2013 09:02:00

5c

Standard Lot#: 23511100A2
Last Changed By: T. GALLEGOS #28847

QAS: T. GALLEGOS #28847
TUCSON PD

Operator: T. GALLEGOS #28847
TUCSON PD

Subject: TEST, SQAP
DOB: 11/11/1987
Sex: F Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	09:02:53
Diagnostic Test	Pass	09:03:21
Air Blank	0.000	09:03:48
0.100 Cal Check	0.097	09:04:07
Air Blank	RFI*	09:04:14
Air Blank	IPS**	09:04:23

*RFI Detect
**Improper Sample

Not a Successfully Completed Test Sequence

4 of 7
Dh

INTOXILYZER 8000
Location:
Serial Number : 80-002759
02/07/2013

09:04:32

5c

Standard Lot#: 23511100A2
Last Changed By: T. GALLEGOS #28847

QAS: T. GALLEGOS #28847
TUCSON PD

Operator: T. GALLEGOS #28847
TUCSON PD

Subject: TEST,SQAP
DOB: 11/11/1987
Sex: F Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	09:05:23
Diagnostic Test	Pass	09:05:50
Air Blank	0.000	09:06:18
0.100 Cal Check	0.097	09:06:36
Air Blank	0.000	09:07:06
Subject Test	0.186*	09:10:14
Air Blank	0.000	09:10:47
Air Blank	0.000	09:11:14
Subject Test	XXX**	09:11:36
Air Blank	0.000	09:12:10

*Deficient Sample
**Invalid Sample
Begin new deprivation period

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location:

Serial Number: 80-002759

02/07/2013

09:12:30

5087
By

5c

Standard Lot#: 23511100A2

Last Changed By: T. GALLEGOS #28847

QAS: T. GALLEGOS #28847

TUCSON PD

Test	g/210L	Time
Air Blank	0.000	09:12:58
Cal Check	0.096	09:13:16
Air Blank	0.000	09:13:46



Operator's Signature

EXHIBIT G-2

6077
Dy

THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY
A.A.C. R13-10-104(A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

SC
3/1/13

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA Specialist Terry Gallegos 28847 AGENCY Tucson Police Department
DATE 2-7-2013 TIME 0856
Intoxilyzer Serial # 80-002759 Location ODE

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0. 100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 097 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE 

DPS Form Exh G-2 (Rev. 05-01)

INTOXILYZER 8000

Location:

Serial Number: 80-002759

02/07/2013

08:56:23

70f7
TS4

5c


Standard Lot#: 23511100A2

Last Changed By: T. GALLEGOS #28847

QAS: T. GALLEGOS #28847

TUCSON PD

Test	g/210L	Time
Air Blank	0.000	08:56:50
Cal Check	0.097	08:57:09
Air Blank	0.000	08:57:38



Operator's Signature