

# Tucson Water- University of Arizona Project Updates

March 25, 2015

**Kelly A. Reynolds, MSPH, PhD, Associate Professor, Director**  
**Jonathan D. Sexton, PhD, Research Specialist, K-12 Outreach**  
**Robert Canales, PhD, Assistant Professor**

Environment, Exposure Science and Risk Assessment Center (ESRAC)  
Mel & Enid Zuckerman College of Public Health  
The University of Arizona, Tucson, AZ

# Endetec Validation



**Kelly A. Reynolds, PhD, Associate Professor, Jonathan D. Sexton, PhD, Research Specialist, K-12 Outreach**

# Endetec

## Pros

- Results in 18 hours or less
- Mechanically read
- Notifications of results
- Semi-quantitative




## Cons

- Longer learning curve
- Sample number dependent on model (ie. 16 or 24)



# Level of Severity



## ENDETEC

Is a trademark of Veolia Water Solutions & Technologies Group

Pathogen Detection System, Inc.  
Suite 4697, Biosciences Complex,  
116 Barrie Street.

Kingston, Ontario, Canada K7L 3N6

Tel: (+1) 613 533 3321

Toll Free (North America): (+1) 866 362 0993


Info@endetec.com - www.endetec.com

Figure 1: TECTA™ Severity Triangle –  
Time-to-Detection provides valuable operational information


# Seeded Water

- Water was seeded with *Escherichia coli* and *Serratia rubidaea*
- No discrepancies between methods for concentrations ranging  $10$ - $10^7$  cfu/100mL
- Concentrations  $<10$  resulted in mixed results
  - Likely due to difficulties in diluting
- Level of severity was in the range of plate count concentrations

Chamber 1 Raw *E coli*, Sept 9, 2012, Tucson Water



Chamber 1 Raw Coliforms, Sept 9, 2012, Tucson Water



# Drinking Water

- 150 drinking water samples collected in the Tucson area
- All negative for total coliforms except 1 sample
  - Low level of severity
  - No discrepancies between methods


# Reclaimed Water

- 18 reclaimed water samples were collected
- 66.7% (12/18) positive for total coliforms
  - No discrepancies between methods
  - Low-Medium level of severity



# Software update 2.0.4

- Improved user interface
  - Decreased learning curve
- Improved quantitative abilities



# Quantitative Validation

- *E. coli* only

Endetec <i>E. coli</i> Concentration (cfu/100mL)	Plate Count Concentration (cfu/100mL)	Endetec Total Coliform Concentration (cfu/100mL)	Plate Count Concentration (cfu/100mL)
10 <sup>8</sup>	2.76E+09	10 <sup>9</sup>	2.76E+09
10 <sup>7</sup>	2.85E+08	10 <sup>8</sup>	2.85E+08
10 <sup>6</sup>	2.72E+07	10 <sup>6</sup>	2.72E+07
10 <sup>5</sup>	2.52E+06	10 <sup>6</sup>	2.52E+06
10 <sup>4</sup>	2.26E+05	10 <sup>5</sup>	2.26E+05
3.07E+03	2.90E+04	10 <sup>4</sup>	2.90E+04
238	2.70E+03	2.38E+03	2.70E+03
36	305	320	305

# Quantitative Validation

- *S. rubidea* only

Endetec Total Coliform Concentration (cfu/100mL)	Plate Count Concentration (cfu/100mL)
10 <sup>7</sup>	4.55E+09
10 <sup>6</sup>	4.75E+08
10 <sup>4</sup>	4.85E+07
1.37E+03	4.20E+06
330	5.15E+05

# Quantitative Validation

- *E. coli* and *S. rubidea*

Endetec <i>E. coli</i> Concentration (cfu/100mL)	<i>E. coli</i> Plate Count Concentration (cfu/100mL)	Endetec Total Coliform Concentration (cfu/100mL)	Total Coliform Plate Count Concentration (cfu/100mL)
10 <sup>8</sup>	2.55E+09	10 <sup>9</sup>	5.95E+09
10 <sup>7</sup>	2.85E+08	10 <sup>8</sup>	6.70E+08
10 <sup>6</sup>	1.90E+07	10 <sup>6</sup>	5.80E+07
10 <sup>5</sup>	2.35E+06	10 <sup>6</sup>	6.30E+06
10 <sup>4</sup>	2.50E+05	10 <sup>5</sup>	6.00E+05
6.55E+03	2.80E+04	10 <sup>4</sup>	7.60E+04
515	2.35E+03	9.13E+03	8.45E+03
53	400	317	1.00E+03
5	27	77	75
1	2	7	6

# Future Work

- Comparison of methods with water of varying quality
  - Microbial and chemical
- Quantitative validation with different bacteria
  - Coliforms and non-coliforms

# Tucson Water Risk Assessment Project

**Robert Canales, PhD, Assistant Professor**  
**Kelly A. Reynolds, PhD, Associate Professor**  
**Sally Littau, BS, MT(ASCP) Health Research Coordinator**

Environment, Exposure Science and Risk Assessment Center (ESRAC)  
Mel & Enid Zuckerman College of Public Health  
The University of Arizona, Tucson, AZ

# Brief Fluoride Summary

- Fluoride analysis has replaced the Chromium-6/Total Chromium analysis due to insufficient data currently collected
- 2 recent news reports suggested Tucson water is low in fluoride concentrations
  - Arizona Daily Star Nov 2, 2014
  - Arizona Daily Wildcat, Nov 11, 2014

# Fluoride Benefits and Risks

- At low intake levels, fluoride has can have therapeutic value in the prevention of dental caries
- Slightly higher levels can lead to dental fluorosis - a condition in which the enamel covering of the teeth fails to crystallize properly
  - More of a concern for children during the period of enamel development
  - Possible problems range from barely discernible markings to brown stains and surface pitting
  - Some studies show that climate may be a factor as well
- Prolonged high intake can result in skeletal fluorosis - a condition which may increase bone brittleness and risk of bone fracture
- In high-dose cases, severe bone abnormalities can develop



# Current Fluoride Guidelines

## —Regulated by EPA

- Maximum contaminant level goal (MCLG) is 4.0 mg/L (4.0 ppm)
- Enforceable MCL is 4.0 mg/L
- Non enforceable secondary level of 2 mg/L

# American Dental Association

- ADA recommendation
  - Optimum water fluoride concentration of 0.7 to 1.2 ppm
  - Was established to maximize the decay preventive benefit
  - 2014 article by American Academy of Pediatric Dentistry “Guideline on Fluoride Therapy”
    - Department of Health and Human Services
    - Recently proposed 0.7 as the upper limit due to additional sources of fluoride available (toothpaste, for example)

# Agency for Toxic Substances and Diseases

- ASTDR minimal risk level for sodium fluoride
  - Oral Route: 0.6 mg/kg/day
  - Endpoint: Musculoskeletal (fluorosis, skeletal fracture)
- Other potential risks:
  - High levels: Cancer
  - Low levels: Dental caries

# Questions

- Currently the level of fluoride in Tucson water fluctuates across sampling points and over time
- Does Tucson have plans to fluoridate water?
- Is there anticipation of public concern?
- What are major concerns and considerations?

# Data Files


- Received 71 data files from TW
  - 60 are WQZ files; 11 from sites such as Sunset Ranch, Diamond Bell, Thunderhead etc.
  - May enable us to provide displays or data summaries for data combined over all years
- Contains all laboratory data for
  - Years 2009 to 2014
  - All Tucson water systems
  - Each WQZ file has data for 10 – 36 sampling points

# File Formatting

- Original XML files were archived and copied, and copied files were converted to text (.txt) files for easy upload into statistical software (R)
- Joined all years (2009 – 2014) for a given WQZ
- Used SAMPLE\_DATE field to create 2 fields corresponding to year and month, for further temporal analysis
- Created new data frames extracting values relevant to analysis of Fluoride
- All commands for formatting and analysis are saved in scripts for quality assurance

# Potential and Preliminary Analysis

- Use of boxplots (box and whisker plots) to visualize data summaries




Any outliers are indicated as points beyond the “whiskers”

# Potential and Preliminary Analysis


- Use of boxplots
  - Visualize data from each sampling point across a water zone for a particular year
  - Visualize data from each sampling point across a water zone for the years 2009 – 2014 combined
  - Visualize data from a sampling point for all years by sampling date (month and/or season)




## WQZ.1\_2009



## WQZ.1 2009-2014



## WQZ.1 SP-001



# Future Work

- Continue exploration along the lines of sample plots, data summaries, and trends
- Explore correlations between Fluoride and metals or other water components/characteristics
- If given coordinates, can map data along sampling points across water zones

# Future Work

- Indirectly estimate fluoride dose intake via drinking tap water
  - Use intake data from EPA handbooks or consumption surveys
- Use additional data sources and assumptions to estimate cumulative exposure assessment and dose from multiple sources
- Estimate health risks from tap water and cumulative sources
  - Use of EPA's dose-response information

# Statistical Significance

- “What is the minimum amount of values, in general, that are needed to make the risk assessment model statistically significant for any given parameter?”
- What is the specific statistical test of interest?
  - Do we want to test if concentration values are statistically different from the MCLG of 4.0 mg/L?
  - What is the expected standard deviation or variance?
  - What is the expected effect size or difference in means?

# Statistical Significance

- Assumptions
  - Desired level of significance of 0.05
  - Aim to achieve 80% power
  - One-sample test (test data against a single value such as the MCL)
- Sample size estimate is
  - $n \approx 15$  for a large effect size (0.8)
  - $n \approx 25$  for a medium effect size (0.5)
  - $n \approx 200$  for a small effect size (0.2)
  - Interpretation: to be able to detect a statistically significant difference that is small requires a greater sample size

# Statistical Significance

- An effect size is the difference in means divided by the standard deviation
- Assuming a standard deviation of 0.1 mg/L (from preliminary analysis of data), the difference in means is
  - for a large effect size (0.8), 0.08
  - for a medium effect size (0.5), 0.05
  - for a small effect size (0.2), 0.02
- If testing the difference from the MCLG of 4.0 mg/L, based on preliminary analysis the expected effect size is likely large, requiring a relatively small sample size (~15) to achieve 80% power





# SMARTPHONE FOR WATER QUALITY:

Smartphone Detection from Paper  
Microfluidics for Monitoring Water Safety

**Jeong-Yeol Yoon, PhD, Associate Professor**  
**Kelly A. Reynolds, MSPH, PhD, Associate Professor**

Department of Agricultural & Biosystems Engineering (Yoon)  
Mel & Enid Zuckerman College of Public Health (Reynolds)  
The University of Arizona, Tucson, AZ


# The Idea



Taking reference data



or



Loading sample on the paper microfluidic chip by dipping or pipetting



Taking signal data

Detection @ optimum angle utilizing internal gyro sensor

Scatter from paper is minimized utilizing Mie scatter theory


Filtration by paper fibers

# Innovation


- Both paper microfluidics and smartphone-based biosensor have not been utilized for water quality monitoring (especially for pathogens).
- Method has demonstrated extremely low detection limit (10 pg virus antigens or 10 CFU bacteria per mL sample).

# How it works

FOR PATHOGENS:



no target, mostly singlets



triplet formation with target  
increase in particle diameter


Detection by Mie scatter  
@ optimized angle

FOR CHEMICALS:




Colorimetric assay  
using RGB pixel intensities  
with double normalization  
(to cancel out chip-to-chip variation  
and ambient lighting)

# Filtration by paper fiber








# Smartphone + paper microfluidics



# Optimization of detection angle





# Mie scatter simulation






# Standard curves

With Paper Microfluidics + Smartphone Detection




# Field water samples

With Paper Microfluidics + Smartphone Detection



# Results w/ 1.5 ppm chlorine



With Paper Microfluidics + Smartphone Detection




Able to detect *E. coli* in the presence of chlorine

# Chromium (VI) and Chlorine Detection

Dye Loaded  
In Channel  
Before  
Sample  
Sample Loaded  
& Flows to Dye






Chromium (VI) concentrations were quantified through green absorbance following a dying process mid-channel with diphenylcarbazide (DPC)/H<sub>2</sub>SO<sub>4</sub>.



Chlorine quantified through green absorbance following N,N-diethyl-p-phenylenediamine (DPD) dying.

# Preliminary result for cr(vi)



Detection limit of EPA Method 7196A  
w/ spectrophotometer = 10-20 ug/L

This method = ca. 1 ug/L



# Conclusions

- Paper microfluidics with smartphone detection permits rapid and sensitive water quality detection at environmentally significant levels for customizable targets
  - **Single-cell *E. coli*** detection (assay < 90s)
  - **10 ppb Chromium (VI)** detection (< 10 min)
  - **0.5 ppm Total Chlorine** detection (< 10 min)
- Smartphone-based assay allows mobility for potential in-field, real-time detection
- Technology advancing
  - Improved LED flash technology and smartphone camera resolution
  - Improved app, autosearches optimal light scattering angle

# Multi-channel paper microfluidics

Detection of water quality parameters with paper microfluidics:

pH  
Total Chlorine  
Hardness  
Ca<sup>2+</sup> and Mg<sup>2+</sup>  
*E. coli*  
Chromium (VI)  
Caffeine



# Future work



- Repeat assays of *E. coli* in complex water samples (reuse water)
- Comparison with routine Colilert® monitoring
- Combined microbe detection
- Colorimetric assays for other parameters, including arsenic and dioxin
- Advance virus detection method



# Paper Microfluidics:

## Particle-based Immunoassay for norovirus

Immunoagglutination on paper chip  
Light Scattering Characteristics



**Using antibodies on paper to detect norovirus capsid protein VP1**

**Experiments to be conducted with recombinant norovirus antigen, and deactivated norovirus capsid (both from identified sources)**

# Acknowledgements

- **Tucson Water**
  - Dan Quintanar
- **NSF-WET Center**
  - Dr. Ian Pepper
- **Environment, Exposure Science and Risk Assessment Center (ESRAC)**
  - Dr. Robert Canales
  - Dr. Jonathan Sexton
  - Melissa Valdez, MSPH
  - Sally Littau, BS, MT, (ASCP)
- **Biosensors Lab, University of Arizona**
  - Dr. Jeong-Yeol Yoon
  - Dr. Tu San Park
  - Dr. Scott Angus
  - Katherine McCracken